G-CEM LinkAce[™] TECHNIQUE GUIDE



Prior to use, carefully read the instructions for use.

CEMENTATION **TECHNIQUE** for inlays, onlays, crowns, bridges



Clean, rinse and thoroughly dry the prepared tooth.



Prepare the restoration according to the manufacturer's instructions



Extrude material into restoration. Seat immediately and maintain moderate pressure.

Maintain moderate pressure



Tack cure each surface with a visible light curing unit



Remove excess cement while maintaining moderate pressure.



Light cure each margin for 20 sec. Alternatively, let the material self-cure for 4 min.



Finish and polish margins if necessary.

G-CEM LinkAce[™] TECHNIQUE GUIDE

CEMENTATION **TECHNIQUE** for posts



Clean, rinse and thoroughly dry the post space using paper points.



Prepare the post according to the manufacturer's instructions.




Attach GC Automix Tip for Endo and apply extension tip. Extrude material into root canal and insert post immediately within 1 minute.

STORAGE RECOMMENDATION Store at room temperature, away

Maintain moderate pressure



Remove excess cement.



Light cure each surface / margin for 20 sec.



Let the material set for another 4 min.

